

SIZING CHART

3 3.5	4	2	
	4.5	2.5	21.5
4	5	3	22
			22.5
			23
			23.5
6	7	5	24
6.5	7.5	5.5	24.5
7	8	6	25
7.5	8.5	6.5	25.5
8	9	7	26
			26.5
			27
9.5	10.5	8.5	27.5
10	11	9	28
10.5	11.5	9.5	28.5
11	12	10	29
11.5	12.5	10.5	29.5
	13	11	30
			30.5
			31
			31.5
			32
			32.5 33
	4.5 5 5.5 6 6.5 7 7.5 8 8.5 9 9.5 10 10.5	4.5 5.5 5 6 5.5 6.5 6 7 6.5 7.5 7 8 7.5 8.5 8 9 8.5 9.5 9 10 9.5 10.5 10 11 10.5 11.5 11 12 11.5 12.5 12 13 12.5 13.5 13 14 13.5 14.5 14 15 14.5 15.5	4.5 5.5 3.5 5 6 4 5.5 6.5 4.5 6 7 5 6.5 7.5 5.5 7 8 6 7.5 8.5 6.5 8 9 7 8.5 9.5 7.5 9 10 8 9.5 10.5 8.5 10 11 9 10.5 11.5 9.5 11 12 10 11.5 12.5 10.5 12 13 11 12.5 13.5 11.5 13 14 12 14 15 13 14.5 15.5 13.5

All SCARPA non-plastic footwear uses European sizing

- * 1 Euro whole size = 6.6 mm = 0.26 inches
- * 1 US whole size = 8.4 mm = 0.33 inches
- * The 30 Euro sizes above cover the same size range as 24 US sizes.
- * More Euro sizes provide a better, more precise fit for your intended use.

Rock Shoes: downsize 1/2 to 2 full sizes from street shoe size

* downsizing depends on model, intended use, and personal preference.

Mountaineering: Upsize (1/2+ sizes) depending on desired fit

* SCARPA plastic mountaineering boots are based on the UK sizing scale.

Ski Boots: All SCARPA ski boots are measured in Mondo sizing

* Highlighted (or not) sizes share the same shell size; the liners are lasted for each 1/2 size. Some skiers may want to downsize up to 1 full Mondo size, depending upon personal preference.